



**968-3620e**

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
01	306 292 12	1	Lenktriebachse siehe EL-Blatt 993-1681	Steering drive axle see page 993-1681
02	306 240 12	4	Achsstrebe	Axle brace
04	509 562 98	4	Schraube	Bolt
05	509 560 98	12	Schraube	Bolt
10	604 678 40	2	Lenkzylinder	Steering cylinder
11	450 620 40	4	Kugelgelenkkopf	Knuckle
12	001 887 12	2	Stößelschalter	Tappet switch
13	349 003 40	1	Stößelschalter	Tappet switch
15	654 249 40	2	Näherungsschalter	Approximate-switch
16	387 500 40	2	Federungszyylinder	Suspension cylinder
18	126 005 12	4	Bolzen	Pin
19	542 624 40	8	Distanzring	Spacer
21	342 540 99	8	Sicherungsring	Safety ring
31	306 287 12	1	Winkelgeber	Angle transmitter
32	408 080 12	1	Stecker	Socket
33	308 536 99	2	Schraube	Screw
34	306 286 12	1	Koppelstange	Toggle link
35	511 163 98	1	Schraube	Screw
36	506 888 98	2	Scheibe	Washer
37	512 453 98	1	Scheibe	Washer

**Einbau - Achse 2 ( 6 x 6 x 6 )  
Axle 2, mounting**

**968-3620e**

Seite/Page 2 / 2