



968-3627

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	198 137 12	1	Lenktriebachse siehe EL-Blatt 198 137 12	Steering drive axle see page 198 137 12
02	306 240 12	4	Achsstrebe	Axle brace
04	125 155 99	4	Schraube	Bolt
05	504 812 98	4	Schraube	Bolt
07	461 899 40	2	Stabsensor	Sensor
08	461 900 40	2	Klemmbuchse	Socket
09	454 672 40	2	Buchse	Bushing
10	604 678 40	2	Lenkzylinder	Steering cylinder
11	450 620 40	4	Kugelgelenkkopf	Knuckle
12	001 887 12	1	Stößelschalter	Tappet switch
15	654 249 40	2	Näherungsschalter	Approximate-switch
17	001 224 12	2	Federungszyylinder	Suspension cylinder
18	194 894 12	4	Bolzen	Pin
19	542 624 40	8	Distanzring	Spacer
21	342 540 99	8	Sicherungsring	Safety ring
22	125 155 99	4	Schraube	Bolt
23	504 812 98	4	Schraube	Bolt
31	306 287 12	1	Winkelgeber	Angle transmitter
32	408 080 12	1	Stecker	Socket
33	308 536 99	2	Schraube	Screw
34	306 286 12	1	Koppelstange	Toggle link
35	511 163 98	1	Schraube	Screw
36	506 888 98	2	Scheibe	Washer
37	512 453 98	1	Scheibe	Washer
38	55163440	1	Stutzen	Socket

Einbau - Achse 3 (6 x 6 x 6 FR Telma)
Axle 3, mounting

968-3627

Seite/Page 2 / 2