

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	311 330 12	1	Lenktriebachse s. EL-Blatt 993-1507	Steering drive axle see page 993-1507
02	000 519 12	2	Tristop-Zylinder	Tri-stop cylinder
03	604 025 40	2	Mutter	Nut
04	604 597 40	1	Lenkstange	Steering rod
05	001 755 12	1	Lenkzylinder	Steering cylinder
06	551 226 40	3	Achsstrebe	Axle bracket
07	504 812 98	2	Schraube	Bolt
08	125 155 99	4	Schraube	Bolt
09	001 887 12	2	Stösselschalter "Öffner"	Tappet switch N.C.
10	421 160 12	1	Stösselschalter "Schliesser"	Tappet switch N.O.
11	592 200 40	4	Prüfanschluß	Test connection
12	224 301 40	4	O-Ring	O-ring
13	224 299 40	4	Druckring	Pressure ring
14	509 890 98	4	Mutter	Nut
15	592 201 40	4	Stutzen	Socket
16	592 049 40	1	Stutzen	Socket
17	192 198 40	1	Dichtring	Seal
18	551 533 40	3	Stutzen	Socket
19	592 048 40	1	Stutzen	Socket
20	192 175 40	1	Dichtring	Seal
22	000 696 12	1	Lenkzylinder	Steering cylinder
23	551 279 40	1	Stutzen	Socket
24	551 454 40	1	Stutzen	Socket
25	551 449 40	1	Stutzen	Socket
26	311 309 12	1	Sicherheitswinkelgeber	Angle transmitter
27	310 320 12	1	Schubstange	Pushrod
28	509 788 98	2	Schraube	Screw
29	510 321 98	4	Scheibe	Washer
31	576 023 40	4	Schlauch	Hose assy.
32	511 113 98	1	Schlauch	Hose assy.
33	592 486 40	1	Schlauch	Hose assy.
34	547 256 40	1	Schlauch	Hose assy.
41	350 564 99	1	Schmiernippel	Grease nipple
42	125 774 99	3	Schraube	Bolt

**Achseinbau 2. Achse
Axle Mounting 2. Axle**

970-3611e

Seite/Page 2 / 2