



**970-3615f**

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	311 331 12	1	Lenktriebachse s. EL-Blatt 993-1508	Steering drive axle see page 993-1508
02	654 643 40	2	Tristop-Zylinder	Tri-stop cylinder
03	604 025 40	2	Mutter	Nut
04	604 597 40	1	Lenkstange	Steering rod
05	304 546 12	1	Lenkzylinder	Steering cylinder
06	551 226 40	3	Achsstrebe	Axle bracket
07	509 560 98	2	Schraube	Bolt
08	509 562 98	4	Schraube	Bolt
09	001 887 12	2	Stösselschalter, "Öffner"	Tappet switch N.C.
10	349 003 40	1	Stösselschalter, "Schliesser"	Tappet switch N.O.
11	592 200 40	4	Prüfanschluß	Test point
12	224 301 40	4	O-Ring	O-ring
13	224 299 40	4	Druckring	Thrust collar
14	509 890 98	4	Mutter	Nut
15	592 201 40	4	Stutzen	Socket
16	592 049 40	2	Stutzen	Socket
17	192 198 40	2	Dichtring	Seal
18	551 533 40	3	Stutzen	Socket
19	592 048 40	1	Stutzen	Socket
20	192 175 40	1	Dichtring	Seal
21	551 279 40	1	Stutzen	Socket
23	000 696 12	1	Lenkzylinder	Steering cylinder
24	551 449 40	2	Stutzen	Socket
25	461 899 40	2	ABS-Sensor	ABS-Sensor
26	461 900 40	2	Klemmbuchse	Socket
27	454 672 40	2	ABS-Buchse kompl.	ABS-Bushing assy.
28	311 309 12	1	Sicherheitswinkelgeber	Angle transmitter
29	310 320 12	1	Schubstange	Pushrod
30	509 788 98	2	Schraube	Screw
31	510 321 98	4	Scheibe	Washer
31	576 024 40	4	Schlauch	Hose assy.
32	592 486 40	1	Schlauch	Hose assy.
33	547 256 40	1	Schlauch	Hose assy.
41	350 564 99	1	Schmiernippel	Grease nipple
42	125 774 99	3	Schraube	Bolt

**Achseinbau 3. Achse  
Axle Mounting 3. Axle**

**970-3615f**

Seite/Page 2 / 2