



**970-3640b**

Seite/Page 1 / 2

<b>Bild-Nr</b> Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
01	305 693 12	1	Verteilergetriebe s. EL-Blatt 993-1108	Distributor gear see page 993-1108
02	654 127 40	1	Notlenkpumpe s. EL-Blatt 993-0086	Emergency steering pump see page 993-0086
03	308 568 99	4	Schraube	Bolt
04	551 451 40	1	Stutzen	Socket
05	634 362 40	1	Stutzen	Socket
06	509 849 98	8	Schraube	Bolt
07	509 877 98	12	Mutter	Nut
08	319 484 99	11	Schraube	Bolt
09	576 226 40	4	Lagerelement	Half of bearing element
10	576 239 40	8	Platte	Plate
11	673 974 40	1	Halter, rechts	Retainer, R.H.
12	673 973 40	1	Halter, links	Retainer, L.H.
13	308 423 99	4	Schraube	Bolt
14	510 109 98	4	Mutter	Nut
15	510 495 98	4	Scheibe	Washer
16	551 301 40	1	Stutzen	Socket
17	621 053 40	1	Stutzen	Socket
18	592 048 40	2	Stutzen	Socket
19	551 635 40	3	Stutzen	Socket
20	673 601 40	1	Schlauch, kpl.	Hose, assy
21	576 058 40	3	Stutzen	Socket
22	510 321 98	8	Scheibe	Washer
23	576 029 40	1	Stutzen	Socket
24	192 175 40	1	Dichtring	Seal ring
25	305 694 12	1	Halter	Retainer
26	125 078 99	2	Mutter	Nut
27	510 321 98	4	Scheibe	Washer
28	511 163 98	2	Schraube	Screw
29	001 961 12	1	Induktivgeber	Ind. transmitter

**Verteilergetriebe Einbau  
Distributor Box Mounting**

**970-3640b**

Seite/Page 2 / 2