



98-6020

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	408 709 40	1	Grundkasten, kpl. best. aus Bild-Nr. 01-36	Basic case, assy. consist. of fig-nos: 01-36
01	408 710 40	1	Grundkasten (SK)	Basic case
02	408 833 40	2	Gleitschuh, unten, kpl. einschl. Bild-Nr. 03-06 (anpassen)	Guide shoe, below, assy. incl. fig-nos: 03-06 (to be adapted)
03	286 500 40	2	Gleitstück (anpassen)	Slider (to be adapted)
04	321 299 99	8	Schraube	Screw
05	003 121 98	8	Schraubensicherung	Bolt lock
06	332 111 99	8	Mutter	Nut
07	393 363 40	2	Obere Führung, kpl. einschl. Bild-Nr. 08-11 (anpassen)	Upper guide, assy. incl. fig-nos: 08-11 (to be adapted)
08	358 322 40	2	Gleitstück (anpassen)	Slider (to be adapted)
09	320 433 99	6	Schraube	Screw
10	332 111 99	6	Mutter	Nut
11	003 121 98	6	Schraubensicherung	Bolt lock
12	408 835 40	2	Achse	Axle
13	408 836 40	4	Buchse	Bush
14	311 390 40	2	Knagge	Driver
15	311 367 40	2	Blech	Plate
16	422 013 40	1	Rohr	Pipe
18	422 006 40	2	Rohr	Pipe
19	504 770 98	6	Kugellager	Ball bearing
20	408 644 40	6	Bolzen	Pin
22	367 877 40	2	Achshalter	Axle stirrup
23	422 007 40	1	Buchse	Bush
24	422 008 40	1	Buchse	Bush
25	350 562 99	2	Schmiernippel	Nipple
26	324 455 40	6	Gewindestift	Thread pin
27	307 825 99	4	Schraube	Bolt
28	343 116 99	4	Federring	Lock washer
29	307 825 99	4	Schraube	Bolt
30	003 818 98	4	Mutter	Nut
31	340 614 99	8	Scheibe	Disc
32	342 105 99	6	Splint	Cotter pin
34	422 009 40	2	Distanzblech	Distance plate
35	307 750 40	4	Schraube	Bolt
36	346 510 99	4	Federring	Lock washer
-	390 887 00		Fett für die Gleitflächen (1 kg.)	Special grease for sliding faces
-	255 616 40	1	Anti-Rutschbelag	Safety rubber

**Grundkasten
Basic Case**

98-6020

Seite/Page 2 / 2