



98-6120

<b>Bild-Nr</b> Fig Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detailj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
00	422 630 40	1	Wippstützentraverse, kpl.	Derricking crossbar, assy.
01	422 629 40	1	Wippstützentraverse (SK)	Derricking crossbar
02	283 448 40	2	Seilrolle, kpl. einschl. Bild-Nr. 03, 04	Sheave assy. incl. fig-nos: 03, 04
03	002 018 98	2	Rollenlager	Roller bearing
04	500 609 99	4	Sprengring	Snap ring
05	342 158 40	1	Achse	Axle
06	342 159 40	2	Distanzrohr L = 102	Distance sleeve
07	342 160 40	1	Distanzrohr L = 39	Distance sleeve
08	332 444 40	2	Bolzen	Pin
09	007 226 98	2	Sicherungsfeder	Locking spring
10	307 804 99	4	Schraube	Bolt
11	343 112 99	4	Federring	Lock washer
12	317 132 40	2	Achshalter	Axle stirrup
20	424 010 40	2	Zwischenseil für alle Variationen	Pendant rope for all variants
21	001 641 98	4	Steckbolzen	Socket pin
22	001 646 98	4	Sicherungsfeder	Locking spring