



**984-0005**

Seite/Page 1 / 2

<b>Bild-Nr</b> Fig Fig Fig Bild nr	<b>ET-Nr</b> Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	<b>Stückzahl</b> Qty Qte Ctd Qta Antal		<b>Gegenstand</b> Description Designation Descripcion Designazione Benaemning
			<b>Motor</b>	<b>Engine</b>
01	420 791 12	1	Kraftstofffiltereinsatz 993-0804	Fuel filter insert
02	420 789 12	1	Ölfiltereinsatz 993-0804	Oil filter insert
03	420 792 12	1	Flachriemen 993-0804	Flat belt
			<b>Luftfilter</b>	<b>Air cleaner</b>
11	988 596 00	2	Luftfiltereinsatz 984-1250	Air cleaner insert
			<b>Hydr. Ölbehälter</b>	<b>Hydr. Oil Tank</b>
21	515 724 40	1	Belüftungsfilter 984-1800	Filter
22	761 143 73	2	Rücklaufilter Einsatz s. EL-Blatt 90-0603 s. EL-Blatt 90-0604	Return oil filter insert see page 90-0603 see page 90-0604
23	958 383 00	2	O-Ring	O-ring
			<b>Getriebe</b>	<b>Gear Box</b>
31	411 000 12	1	Filterpatrone (Getriebe) 993-0803	Element (gear)
			<b>Pneumatik</b>	<b>Pneumatic</b>
41	761 176 73	2	Filterelement 984-1700	Element
60	431 206 73	1	Siebeinsatz	Fuel filter insert
61	979 252 73	1	Dichtung	Seal ring