



Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	133 041 12	1	Armaturenbrett 2, kpl.	Dashboard 2 assy.
02	655 143 40	1	Blindstopfen – Ausführung ohne Standheizung	Dummy plug – design w/o. aux. heating
03	131 313 12	1	Symbolplatte	Symbol plate
04	131 314 12	1	Meldeleuchtenmodul best. aus Bild-Nr. 41-50	Indicator light module consist. of fig-nos: 41-50
05	654 779 40	10	Glühlampe	Bulb
06	654 186 40	1	Zündstartschalter	Ignition switch
07	461 507 40	5	Tastenkippschalter	Push-toggle switch
08	461 230 40	2	Tastenkippschalter	Push-toggle switch
11	551 036 40	1	Tastenkippschalter	Push-toggle switch
12	524 991 40	1	Tastenkippschalter	Push-toggle switch
13	417 386 40	1	Zigaretten-Anzünder	Cigarette lighter
14	490 582 40	1	Einbausteckdose	Built-in socket
15	363 410 40	6	Blindplatte	Dummy plate
16	507 049 98	6	Senkschraube	Countersunk screw
17	490 943 40	6	Rosette	Fitting
18	634 403 40	6	Steckmutter	Nut
41	400 365 12	1	Symbol Differentialsperre längs, gelb	Symbol differential lock longitudinal, yellow
42	400 370 12	1	Symbol Differentialsperre quer, gelb	Symbol differential lock cross, yellow
43	400 794 12	1	Symbol Kranbetrieb, gelb	Symbol crane operation, yellow
44	400 795 12	1	Symbol Hundegang 1, gelb	Symbol crab walk 1, yellow
45	400 796 12	1	Symbol Hundegang 2, gelb	Symbol crab walk 2, yellow
46	400 797 12	1	Symbol Umschaltung 3-Punkt-system, gelb	Symbol select. 3-point-system, yellow
47	400 798 12	1	Symbol Federung gesperrt, gelb	Symbol suspension closed, yellow
48	400 799 12	1	Symbol Achsen halten, gelb	Symbol axles hold, yellow
49	400 800 12	1	Symbol Hundegang, gelb	Symbol crab walk, yellow
50	400 801 12	1	Symbol Achsen heben, gelb	Symbol axles lift, yellow
55	551 639 40	1	Radiorecorder	Radio recorder

**Armaturenbrett 2
Dashboard 2**

984-2112a

Seite/Page 2 / 2