



987-1910

Seite/Page 1 / 2

| Bild-Nr Fig Fig Fig Fig Bild nr | ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr | Stückzahl Qty Qte Ctd Qta Antal | | Gegenstand Description Designation Descripcion Designazione Benaeming |
|--|--|--|-------------------|--|
| 01 | 889 695 40 | 1 | Abdeckblech | Cover plate |
| 02 | 507 182 98 | 4 | Schraube | Screw |
| 03 | 889 698 40 | 1 | Einbau Gaspedal | Accelerator pedal mounting |
| 09 | 509 940 98 | 6 | Schraube | Screw |
| 10 | 509 870 98 | 6 | Mutter | Nut |
| 11 | 340 507 99 | 6 | Scheibe | Washer |
| 12 | 576 306 40 | 1 | Fußtaster | Foot switch |
| 13 | 307 671 99 | 2 | Schraube | Screw |
| 14 | 334 649 99 | 2 | Mutter | Nut |
| 15 | 322 310 00 | 4 | Scheibe | Washer |
| 16 | 269 387 40 | 1 | Gummitülle | Grommet |
| 21 | 889 696 40 | 1 | Fußkasten | Foot box |
| 22 | 889 697 40 | 1 | Platte | Plate |
| 23 | 320 471 99 | 7 | Schraube | Screw |
| 24 | 509 869 98 | 7 | Mutter | Nut |
| 25 | 307 597 99 | 1 | Schraube | Screw |
| 26 | 509 870 98 | 4 | Mutter | Nut |
| 27 | 307 760 99 | 3 | Schraube | Screw |
| 33 | 635 279 40 | 1 | Bremspedal | Brake valve |
| 35 | 000 170 12 | 1 | Handbremsventil | Hand brake valve |
| 45 | 634 425 40 | 1 | Geräuschdämpfer | |
| 58 | 621 798 40 | 1 | Pedalüberzug | |
| 63 | 551 617 40 | 2 | Stutzen | Socket |
| 66 | 192 198 40 | 1 | Dichtring | Seal ring |
| 73 | 313 120 99 | 1 | Verschlußschraube | Screw plug |