


**993-0304**



**993-0304**

Seite/Page 2 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	662 159 40	1	Lenkachse	Steering axle
01	400 145 12	1	Achsgehäuse	Axle housing
02	997 415 00	2	Wellenmutter	Nut
03	777 094 73	2	Büchse	Bushing
04	997 103 00	2	Nasenscheibe	Gib disk
05	363 017 99	2	Kegelrollenlager	Roller bearing
06	350 342 99	2	Zylinderschraube	Screw
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	511 340 98	2	Wellendichtring	Shaft seal ring
10	760 674 00	2	Radnabe	Wheel hub
11	760 675 00	2	Verschlußkappe	Cap
12	780 502 73	20	Radbolzen	Wheel stud
13	997 471 00	2	Bremstrommel	Brake drum
14	-	4	Schraube	Bolt
15	-	2	Bremse siehe EL-Blatt 90-3072	Brake see page 90-3072
16	772 394 73	1	Spurhebel, links	Track rod lever, l.h.
17	772 393 73	1	Spurhebel, links	Track rod lever, l.h.
19	772 404 73	1	Lenkspurhebel, links	Steering lever, l.h.
21	510 517 98	12	Schraube	Bolt
22	319 305 99	4	Zylinderschraube	Bolt
23	350 562 99	4	Schmiernippel	Grease nipple
24	763 206 73	1	Spurstange	Track rod
25	320 389 99	3	Zylinderschraube	Bolt
26	511 416 98	2	O-Ring	O-ring
27	771 047 00	1	Deckel	Cover
30	770 523 00	2	Lagerbüchse, unten	Bearing bush, lower
31	780 163 73	2	Scheibe	Washer
32	956 719 00	2	Anlaufscheibe	Stop washer
33	771 346 00	2	Lagerbüchse, oben	Bearing bushing, top
35	772 366 73	2	Achsschenkelbolzen	Steering knuckle pin
36	771 284 00	2	Federbock	Spring block
37	319 311 99	2	Zylinderschraube	Bolt
38	345 629 99	2	Zylinderstift	Parallel pin
40	400 136 12	2	Achsschenkel	Steering knuckle
45	777 331 73	2	Schraube	Bolt
46	334 686 99	2	Mutter	Nut

**Lenkachse 7  
Steering Axle 7**

**993-0304**

Seite/Page 3 / 3