



**993-0567**

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	000 447 12	1	Längenwinkelgeber, kpl.	Longitudinal angle transmitter
01	420 072 12	1	Neigungsgeber	Angle transmitter
02	421 047 12	1	Längengeber	Longi transmitter
03	420 073 12	1	Deckel	Cover
04	420 074 12	1	Dichtung	Gasket
05	420 075 12	1	Deckelachse	Cover axle
06	421 059 12	1	Schraube	Screw
07	420 845 12	1	Kabel	Cable
08	300 038 99	1	Seilkausche	Grummet
09	420 162 12	1	Seilklemme	Rope clamp
10	420 841 12	1	Stopper, kpl.	Stopper, assy.
11	420 840 12	1	Führungssachse	Guide axle
12	420 842 12	1	Führungsrolle	Guide roller
13	420 843 12	1	Schleiffringsatz, kpl.	Slip ring, assy.
14	420 844 12	1	Kontaktsatz, kpl.	Contact set, assy.
15	420 076 12	1	Platine	Circuit board
20		7	Schraube	Screw
-	422 226 12	1	Federpaket	Spring

**Längenwinkelgeber**  
**Longitudinal Angle Transmitter**

**993-0567**

Seite/Page 2 / 2