



993-0881

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	875 975 40	1	Lenkachse	Steering axle
01	400 591 12	1	Achsgehäuse, kpl.	Axle housing, assy.
02	997 415 00	2	Wellenmutter	Nut
03	350 342 99	2	Schraube	Screw
04	997 103 00	2	Nasenscheibe	Gib disc
05	363 017 99	2	Kegelrollenlager	Roller bearing
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	511 340 98	2	Dichtring	Seal ring
09	777 094 73	2	Buchse	Bushing
10	760 674 00	2	Radnabe	Wheel hub
11	760 675 00	2	Verschlusskappe	Cap
12	780 502 73	20	Radbolzen	Wheel bolt
13	771 138 00	2	Bremstrommel	Brake drum
14	320 271 99	4	Schraube	Bolt
17	400 134 12	1	Hebel, links	Lever, l.h.
18	400 135 12	1	Hebel, rechts	Lever, r.h.
19	772 404 73	1	Hebel, rechts	Lever, r.h.
20	308 417 99	20	Schraube	Bolt
22	771 047 00	1	Deckel, links	Cover, l.h.
24	350 562 99	2	Kegelschmiernippel	Fitting
26	763 205 73	1	Spurstange	Steering track rod
27	770 523 00	2	Lagerbuchse, unten	Bush, lower
28	965 719 00	2	Anlaufscheibe	Stop washer
30	771 346 00	2	Lagerbuchse	Bush
31	761 708 73	2	Achsschenkelbolzen	Steering knuckle pin
32	780 163 73	2	Anlaufscheibe	Stop washer
33	400 136 12	2	Achsschenkel	Steering knuckle
34	777 331 73	2	Schraube	Bolt
35	320 112 99	2	Mutter	Nut
39	-	2	Bremse siehe EL-Blatt 90-3298	Brake see page 90-3298
50	320 407 99	3	Schraube	Bolt
51	771 284 00	2	Federbock	Spring block
52	320 250 99	4	Schraube	Bolt
53	319 311 99	2	Schraube	Bolt
54	400 498 12	2	Kappe	Cap
55	345 629 99	2	Zylinderstift	Parallel pin
56	511 416 98	2	O-Ring	O-ring
57	350 564 99	2	Kegelschmierkopf	Grease nipple
58	400 363 12	2	Verschlusskappe	Tube pole cap

**Achse 1
Axle 1**

993-0881

Seite/Page 3 / 3