


993-0901



993-0901

Seite/Page 2 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	888 913 40	1	Lenkachse	Steering axle
01	400 536 12	1	Achsgehäuse, kpl.	Axle housing, assy.
02	997 415 00	2	Wellenmutter	Nut
03	350 342 99	2	Schraube	Screw
04	997 103 00	2	Nasenscheibe	Gib disc
05	363 017 99	2	Kegelrollenlager	Roller bearing
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	400 528 12	2	Dichtring	Seal ring
09	777 094 73	2	Buchse	Bushing
10	763 087 12	2	Radnabe	Wheel hub
11	760 675 00	2	Verschlußkappe	Cap
12	780 787 12	20	Radbolzen	Wheel bolt
13	779 925 73	2	Bremstrommel	Brake drum
14	320 271 99	4	Schraube	Bolt
17	400 537 12	1	Hebel, links	Lever, l.h.
18	400 538 12	1	Hebel, rechts	Lever, r.h.
19	400 087 12	1	Hebel,links	Lever, r.h.
20	513 056 98	8	Zylinderschraube	Bolt
21	350 385 99	3	Zylinderschraube	Bolt
22	400 535 12	1	Deckel, links	Cover, l.h.
23	511 416 98	2	O-Ring	O-ring
24	350 562 99	2	Kegelschmiernippel	Fitting
25	350 564 99	2	Kegelschmiernippel	Fitting
26	763 206 73	1	Spurstange	Steering track rod
27	770 523 00	4	Lagerbuchse, unten	Bush, lower
28	965 719 00	2	Anlaufscheibe	Stop washer
31	780 498 73	2	Achsschenkelbolzen	Steering knuckle pin
32	780 163 73	2	Anlaufscheibe	Stop washer
33	771 284 00	2	Federbock	Spring block
34	319 311 99	2	Zylinderschraube	Bolt
35	345 629 99	2	Zylinderstift	Parallel pin
36	400 078 12	2	Achsschenkel	Steering knuckle
37	777 331 73	2	Schraube	Bolt
38	320 112 99	2	Mutter	Nut
39	-	2	Bremse siehe EL-Blatt 993-0818	Brake see page 993-0818
50	514 091 98	12	Schraube	Bolt
51	320 250 99	4	Zylinderschraube	Bolt
52	400 088 12	2	Rohr	Pipe
53	780 500 73	2	Rohr	Pipe

**Lenkachse
Steering Axle**

993-0901

Seite/Page 3 / 3