



993-1117

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal	Gegenstand Description Designation Descripcion Designazione Benaemning	
00	119 190 12	1	Gegengewichtshubzylinder	
01	460 038 12	1	Zylinderrohr	Cylinder barrel
02	460 039 12	1	Klobenstange	Piston rod
03	460 040 12	1	Zylinderkopf	Cylinder head
04	460 041 12	1	Kolben	Piston
05	978 372 73	1	Rückschlagventil	Non-return valve
06	978 373 73	1	Verschlußschraube	Screw plug
07	460 042 12	1	Ventil	Valve
08	431 551 73	1	Passstift	Dowel pin
09	307 629 99	1	Schraube	Bolt
10	431 553 73	1	Scheibe	Washer
11	318 798 99	4	Schraube	Bolt
12	255 171 40	1	Verschlußschraube	Screw plug
13	460 043 12	1	Leitungsbruchventil	Pipe burst valve
14	313 802 99	1	Verschlußschraube	Screw plug
15	460 044 12	1	Dichtring	Seal ring
20	460 045 12	1	Dichtungssatz	Seal kit
21	460 046 12	1	Abstreifer	Scraper
22	460 047 12	1	Dichtring	Seal ring
23	460 048 12	1	Dichtring	Seal ring
24	460 049 12	4	Führungsband	Guide strap
25	460 050 12	1	O-Ring	O-ring
26	460 051 12	1	Stützring	Support ring
27	460 052 12	1	Kolbendichtung	Piston seal
28	460 053 12	1	Dichtring	Seal ring
29	460 054 12	2	Führungsband	Guide strap
30	460 055 12	1	O-Ring	O-ring
31	460 056 12	2	Stützring	Support ring

Hubzylinder
Lift cylinder

993-1117

Seite/Page 2 / 2