





**993-1395**

Seite/Page 2 / 3

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
00	310 010 12	1	Lenkachse	Steering axle
01	401 359 12	1	Achsgehäuse	Axle housing
02	997 415 00	2	Wellenmutter	Nut
03	777 094 73	2	Büchse	Bushing
04	997 103 00	2	Nasenscheibe	Gib disk
05	361 580 99	2	Kegelrollenlager	Roller bearing
06	350 342 99	2	Zylinderschraube	Screw
07	534 023 99	2	Kegelrollenlager	Roller bearing
08	400 528 12	2	Radialwellendichtring	Seal ring
10	979 109 73	2	Radnabe	Wheel hub
11	760 675 00	2	Verschlußkappe	Cap
12	780 787 73	20	Radbolzen	Wheel stud
13	779 925 73	2	Bremstrommel	Brake drum
14	321 991 99	4	Schraube	Bolt
15	401 356 12	2	Bremse siehe EL-Blatt 993-1396	Brake see page 993-1396
16	400 538 12	1	Spurhebel, links	Track rod lever, l.h
17	400 537 12	1	Spurhebel, rechts	Track rod lever, r.h.
18	320 250 99	4	Zylinderschraube	Steering lever, r.h.
19	350 564 99	4	Kegelschmierkopf	Grease nipple
21	514 091 98	12	Schraube	Bolt
24	763 207 73	1	Spurstange	Track rod
25	319 301 99	6	Zylinderschraube	Bolt
27	997 202 00	2	Deckel, links	Cover
28	401 289 12	2	Verschlußkappe	Tube pole cap
30	770 523 00	4	Lagerbüchse	Bearing bush
31	780 163 73	2	Scheibe	Washer
32	956 719 00	2	Anlaufscheibe	Stop washer
33	400 297 12	2	Rohr	Pipe
34	780 500 73	2	Rohr	Pipe
35	997 473 00	2	Achsschenkelbolzen	Steering knuckle pin
40	400 689 12	1	Achsschenkel	Steering knuckle
41	400 690 12	1	Achsschenkel	Steering knuckle
45	777 331 73	2	Schraube	Bolt
46	334 686 99	2	Mutter	Nut
50	400 361 12	2	Polrad	Pole wheel
51	400 362 12	2	Buchse	Bushing

**Nachlaufachse  
Caster axle**

**993-1395**

Seite/Page 3 / 3