



993-1509

Seite/Page 1 / 2

Bild-Nr Fig Fig Fig Fig Bild nr	ET-Nr Part-No No. de Piece No. de Pieza No. del Pezzo Detalj nr	Stückzahl Qty Qte Ctd Qta Antal		Gegenstand Description Designation Descripcion Designazione Benaemning
01	133 526 12	1	Bedienkasten kpl.	Operation Box, assy.
02	412 408 12	1	Abdeckplatte m. Dichtung	Covering plate, with gasket
03	412 409 12	1	Frontplatte	Front panel
04	511 657 98	10	Schraube	Screw
05	412 411 12	1	Blindblende	Blind plate
06		2	Schraube	Screw
07	412 412 12	1	Deckel	Cover
08	420 456 12	1	Verschluß	Fastener
09	420 424 12	1	Ersatzschlüsselpaar	Spare key, pair
10	422 026 12	2	Scharnier	Hinge
11	343 265 99	8	Schraube	Screw
12	334 649 99	8	Mutter	Nut
13	401 427 12	1	Gasdruckfeder	Gas operated positioner
14	422 029 12	4	Schraube	Screw
15	422 028 12	2	Gabelkopf	Fork end
16	412 410 12	1	Anzeigegerät	Indicator
17	420 359 12	8	Schalter	Switch
18	412 414 12	2	Drucktaster, kpl.	Push button, assy.
19	973 922 73	2	Relaissockel	Relay base
20	515 743 40	2	Relais	Relay
21		2	Diode	Diode
22	420 347 12	1	Buchsengehäuse 44pol.	Socket shell 44pol.
23	551 325 40	34	Buchsenkontakt ø 1,6mm	Female contact
24	592 300 40	3	Buchsenkontakt ø 1,6mm	Female contact
25	421 195 12	1	Buchsengehäuse 9pol.	Socket shell 9pol.
26	420 099 12	-	Buchsenkontakt	Female contact
31	412 416 12	1	Drucktaster	Push button
32	401 414 12	1	Leuchtdiode	Diode
33	401 423 12	1	Symbol	Symbol
34	420 351 12	1	Kontaktelement	Contact element

**Bedienkasten
Operation Box**

993-1509

Seite/Page 2 / 2